## DRILL TEMPLATE FOR

MODEL: EVO PRO 16"

## This template is for under counter mounting

Drill (8) holes approximately 3/4" deep where marked  $\oplus$  by using a NO. 42(.094") drill bit

## FRONT

(Folding Line)