

# Installation Guide

## EVO-SM1B

### EVO-SM1B

To mount the EVO-SM1B mounting bracket kit, you will need the following materials: 1. EVO-SM1B fixed mount scanner kit for the EVO-TP4. 2. Philip's head screwdriver. 3. The Code brand CR1000 2D scanner

1

Choose your desired angle bracket from the mounting kit. Using the two silver screws included in the mounting kit, attach the chosen bracket to the scanner.



2

Place your POS-X TP4 Face down on a soft material to avoid scratches. Remove the two middlemost screws from the bottom of the back of the screen

3

Using the two black screws included in the mounting kit, attach the assembled fixed mount scanner and connect the scanner's USB cable to any of the USB ports on the TP4



For more information or assistance with installation, please contact our 24/7 free tech support at 360-738-8433 x5 or email us at [customerservice@pos-x.com](mailto:customerservice@pos-x.com)